

Max Min Thermometer



Digital indoor & outdoor thermometer.

- simultaneously displays outdoor & indoor temperature
- programmable high/low temperature alarm
- detachable outdoor probe supplied
- temperature range -49.9 to 69.9°C

This digital max/min and in/out thermometer features an easy to read dual display.

The thermometer simultaneously displays both the in (internal sensor) and the out (remote sensor) as well as the max/min temperatures at the push of a button.

The instrument also features a programmable, audible high/low alarm (remote probe only).

Each unit is powered by an AAA battery and is supplied with a small, water resistant, detachable remote probe with a three metre PVC lead for outside temperatures.

The max/min thermometer is housed in an ABS case which incorporates a foldaway stand and a keyhole slot for hanging on the wall.

Specification	Max/Min in & out thermometer
Range in	-19.9°C to 69.9°C
Range out	-49°C to 69.9°C
Resolution	0.1°C / °F (switchable)
Accuracy	+/- 1°C +/- 1 Digit
Battery	1.5 volt AAA
Battery life	1000 HOURS
Sensor Type	Thermistor
Display	Custom dual LCD
Dimensions	20x65x97mm
Weight	100g