

SuperFast Thermapen Digital thermometer

The new SuperFast Thermapen thermometer is now splash-proof and incorporates a number of additional features including an 0.1°C resolution over the entire range. However the SuperFast Thermapen can be switched to 1°C resolution by the user, if required, via a switch in the battery compartment, this also applies if °F is required.

The battery life is now increased to 1,500 hours and the auto-off facility is increased to 10 minutes but this feature can be disabled, allowing continuous monitoring of temperature.

The SuperFast Thermapen incorporates a larger digital display with a precise read-out of temperature over the range of -49.9 to 299.9°C with a 0.1°C resolution and an improved accuracy of ±0.4°C over the range of -49.9 to 199.9°C, thereafter ±1°C. Both low battery (icon) and open circuit indication are also displayed, when applicable. Each SuperFast Thermapen is powered by two 3 volt CR2032 lithium coin cell batteries with a minimum life expectancy of 1,500 hours.



- Biomaster casing reduces bacterial growth
- larger digital display
- water-resistant case

specification	SuperFast Thermapen
range	-49.9 to 299.9°C
resolution	0.1°C/°F (or 1°C above - user selectable)
accuracy	±0.4°C (-49 to 199.9°C) ±1°C (200 to 300°C)
battery	2 x 3 volt CR2032 lithium coin cell
battery life	1500 hours
sensor type	K thermocouple
display	14.3 mm LCD
dimensions	19 x 47 x 153mm
weight	97 grams

Suggested uses:

New improved casing

The casing is manufactured from a new washable "Biomaster" material that reduces bacteria growth and the ergonomic rubber seal reduces the risk of the ingress of water or dust. The case comes in a variety of colours, so you can separate the instruments uses as suggested in the table on the right. As well as being water resistant, it is still 'probably' the fastest reading contact thermometer on the market today. The true temperature of a product can be tested in under four seconds.

○ white	bakery & dairy products
● yellow	cooked meats
● green	salad & fruit products
● red	raw meat
● blue	raw fish